

[Type here]

PAINTCOR

SUPREME QUALITY *Since 1986*

2025 Revision

AQUASEAL RUBBER

Description and Application

CATEGORY

Waterproofing

DESCRIPTION

AquaSeal Rubber is a highly flexible acrylic waterproofing paint. The system has been designed to provide high elasticity, durability and UV resistance.

FEATURES

- Waterproof
- Can take ponding water
- Excellent Flexibility
- 100% UV stable

AREAS OF USE

- Flat deck roofs
- Roof Bolt Patches
- Over laps
- Parapet walls
- Window sills
- Water Proofing any flat surface

SURFACE PREPARATION AND APPLICATION

New slab (flat deck roof)

Clean surface down to remove all dust and loose, friable material. Ensure the surface is dry. Apply by Brush or Roller.

1. Apply 1 coat of Paintcor AcrySeal Acrylic Sealer, diluted 1:1 with water to the entire deck and parapet walls. Allow to dry. If you suspect that the deck is damp or still green (wet) then Paintcor's CemenTek Sealer must be used in place of AcrySeal Acrylic Sealer. Please see CemenTek data sheet. NOTE: If AcrySeal is used as a sealer on damp or green (wet) new flat deck, before waterproofing, blistering of the system may occur after drying.

[Type here]

PAINTCOR

SUPREME QUALITY *Since 1986*

2. Apply 1 thick coat of AquaSeal Rubber to the sealed deck. Bed the membrane into the still wet AquaSeal Rubber, using a ribbed roller or paint brush with a dabbing action. Apply small areas at a time as it is essential that the AquaSeal Rubber coat is still wet when applying the membrane. Allow the system to dry.
3. Apply 2 or 3 more coats of AquaSeal Rubber to completely seal and saturate the membrane. Allow drying between coats.
4. You may apply Paintcor Ruvacryl, Elegance or Brilliance as a final coat in the colour of your choice, or Aquaseal Rubber can be left as a final coat should the colour be suitable.

Guarantee Terms and Conditions

5 Years

1. New Top coats of AquaSeal Rubber to be applied after 5 years and thereafter when necessary.
2. All down pipes are to be kept clean and open.
3. Periodically clean all debris from the roof.
4. Subject to a Dry film thickness of 200 micron. (minimum of 4 coats @ 8 square meters per litre)

NOTE: It is important to inspect your waterproofing system annually for any defects. Failure to adhere to these conditions will void your guarantee.

APPLICATION EQUIPMENT

Apply by Brush, Sheepskin/Synthetic Roller or Spray

CLEANING EQUIPMENT

Clean all equipment with water immediately after use.

STORAGE

Keep stored in cool, dry conditions and away from children.